

BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTIONS CAREFULLY. FOLLOW THEM STEP BY STEP. CAUTION:

- 1. ADULT SUPERVISION IS REQUIRED DUE TO SMALL PARTS. CARE SHOULD BE TAKEN IN THE UNPACKING AND ASSEMBLY OF THE PRODUCT.
- 2. ASSEMBLE ON SOFT SURFACES TO PREVENT DAMAGE TO THE PRODUCT FINISH.
- **3. MAKE SURE ALL PARTS ARE INCLUDED BEFORE ASSEMBLY.**

ASSEMBLY TOOLS REQUIRED

RUBBER MALLET SCREWDRIVER 89 lbs. (40.3 kg) WARNING!!! This unit is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than the maximum weights indicated may result in 30 lbs. instability causing possible injury. Furniture can (13.6 kg) tip over or break if improperly moved. Have a friend help to lift and carry the unit to it's new location. 30 lbs. (13.6 kg)

Need Assistance? Call 800-639-3803 or visit www.fourstari.com

PARTS AND HARDWARE

BEFORE YOU BEGIN, PLEASE FOLLOW ASSEMBLY INSTRUCTIONS CAREFULLY. FOLLOW THEM STEP BY STEP.

HARDWARE LIST

PARTS LIST

							-
10	9	8	7	6	5		
FOOT W/PIN	WHITE GLUE	WOODEN DOWEL	L BRACKET 20MM L BRACKET 0.79"	12MM SCREW 0.47" SCREW	38MM SCREW 1.49" SCREW	PART NAME	
					(+)mmmmm>>	LINE-ART DRAWING	
3cm x 1.3cm 1.18" x 0.51"	N/A	0.6 x 3cm 0.23" x 1.18"	2 x 2cm 0.79" x 0.79"	1.2cm Flat Head 0.47" Flat Head	3.8cm Flat Head 1.49" Flat Head	SIZE	
4 PCS	1 PC	6 PCS	2 PCS	4 PCS	12 PCS	QTY	


1 PC	34 x 23 x 1.2cm 13.38" x 9.05" x 0.47"		SIDE BOTTOM SHELF	G
1 PC	29.5 x 23 x 1.2cm 11.61"x9.05"x0.47"		SIDE CENTER SHELF	ц
1 PC	53.4 x 9 x 1.2cm 21.02" x 3.54" x 0.47"		BOTTOM BACK PANEL	ц
2 PCS	53.4 x 3.5 x 1.2cm 21.02" x 1.37" x 0.47"		CROSSBAR	D
1 PC	71.4 x 23 x 1.2cm 28.11" x 9.05" x 0.47"		RIGHT SIDE PANEL	C
1 PC	71.4 x 23 x 1.2cm 28.11" x 9.05" x 0.47"		LEFT SIDE PANEL	в
1 PC	80 x 39.5 x 1.5cm 31.5° x 15.55° x 0.59°		TOP PANEL WITH THE CAP INSERTED	A
1 PC	3.4 x 3.4 x 3.8cm 1.34" x 1.34" x 1.49"	Ģ	FOOT	ω
1 PC	3.4 x 3.4 x 21.4cm 1.34" x 1.34" x 8.42"		MEDIUM TUBE	2
1 PC	3.8 x 3.8 x 44cm 1.49' x 1.49'' x 17.32''		LONG TUBE	1
QTY	SIZE	LINE-ART DRAWING	PART NAME	
		AKISLIS		


ASSEMBLY INSTRUCTIONS STEP 1 ATTACH L-BRACKETS (7) TO BOTH CROSSBARS (D) USING SCREWS (6). D **UNFINISHED SIDE UP** 0 (7) L BRACKET 20MM (0.79") - 2 PCS (D) CROSSBARS - 2 PCS (6) 12MM (0.47") SCREW - 2 PCS **STEP 2** ATTACH MEDIUM TUBE (2) TO INSERT CAP. DO NOT OVER TIGHTEN TUBE. (2) 21.4CM (8.42") MEDIUM TUBE - 1PC

Need Assistance? Call 800-639-3803 or visit www.fourstari.com


STEP 3

INSERT DOWELS (8) INSERT ONLY HALF OF THE DOWEL INTO THE TOP OF SIDE PANELS (B) & (C) WITH GLUE (9).






STEP 7 ATTACH PLASTIC FOOT W/PIN (10) TO END OF SIDE PANELS (B) & (C) WITH MALLET.




STEP 8

ATTACH SIDE CENTER SHELF (F) TO SIDE PANEL (C) USING SCREWS (5). ATTACH LONG TUBE (1) TO MEDIUM TUBE (2). DO NOT OVER TIGHTEN TUBE.




STEP 9 ATTACH SIDE BOTTOM SHELF (G) TO SIDE PANEL (C) USING SCREWS (5). ATTACH FOOT (3) TO LONG TUBE (1). DO NOT OVER TIGHTEN FOOT.



(G) SIDE BOTTOM SHELF - 1 PC

(3) 3.8CM (1.49") FOOT - 1 PC

(+)))))))))>> (5) 38MM (1.49") SCREW - 2 PCS




To clean the computer desk, wipe with soft, dry cloth. Apply a small amount of cleaning solution to the cloth if required. Do not use abrasive cleaners in order to prevent the scratching the surfaces.

FINISHED

WARNING!!!

This unit is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than the maximum weights indicated may result in instability causing possible injury. Furniture can tip over or break if improperly moved. Have a friend help to lift and carry the unit to it's new location.



LIMITED 90 DAY WARRANTY

This product is warranted to be free from defects in material and workmanship for a period of 90 days from date of purchase. Warranty is valid for the original purchaser only; proof of purchase from an authorized retailer required. Warranty is limited to replacement of missing and/or defective part(s). If a part is proven defective within the term of this warranty, manufacturer will furnish a replacement part at no cost. No assembly or labor included. This warranty is your sole remedy of product defect and does not cover damage due to mishandling, neglect, moisture, misuse, abuse or non-residential use. The manufacturer is not responsible for incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.



Do you have any questions ? Missing small parts or hardware? If you need assistance with the assembly of your COMPUTER DESK please contact our Customer Service Department by visiting www.fourstari.com or emailing us at support@fourstari.com or call us at 508-473-7688 or 800-639-3803 or write us at Fourstar Group Customer Service, 26840 Fargo Ave., Suite C, Bedford Heiahts, OH 44146.

Printed in Malaysia

STOP!

Missing Small Parts Or Hardware Or Need Assistance?

No Need To Go Back To The Store!

The store where you made your purchase does not stock hardware for this item. If you need hardware or small parts, contact Customer Service. We will happily ship your part, free of charge, <u>within 48 hours</u> of your request.

Please provide the following information:

- Name of the store purchased from.
 - Date of purchase.
- Item, model, style or SKU number listed on the instructions or box.
- Description of the actual item in question.
 - Part number, description of the part and quantity needed.
 - Copy of proof of purchase from an authorized retailer is required

This information will help use fulfill your request efficiently.

Contact Customer Service: Email us at support@fourstari.com or visit www.fourstari.com

Or Call Us At (508) 473-7688 or (800) 639-3803

Hours of Operation are: Monday – Friday 9am to 4pm Eastern Time